

# MRX.ptzController



Control unit for operating PTZ cameras and user menu for MRX.marine

## Quick Start Guide

### System Overview

The MRX.marine system is a modular solution for use in port and offshore environments. It consists of:


- \* One or more camera modules (some with PTZ functionality: pan, tilt, zoom).
- \* MRX.ptzController: A control unit for remote control of the cameras.
- \* Touch monitor interface for system configuration and control.

The PTZ capabilities of the cameras are visualised by icons.

### Hardware description MRX.ptzController

#### Joystick


- Movement axes:
- \* X-axis: Left/right (pan).
  - \* Y-axis: Forward/backward (tilt).
  - \* Z-axis (rotation): Zoom control.



Automatic reset: The joystick returns to the neutral centre position when released.

#### Push buttons

- \* Button 1: Context-dependent function (e.g. camera selection, full-screen mode).
- \* Button 2: Switch between camera display and user menu.



### Operating modes

#### Camera display mode

- \* Primary function: Display, selection and control of cameras.
- \* Control options:
  - Joystick movement (X/Y axis): Pan/tilt of the selected camera (if supported).
  - Joystick rotation (Z axis): Zoom control (if supported).
  - Button 1 + joystick (left/right): Cyclical selection of cameras on the active screen.
  - Button 1 + joystick (forward/backward): Change the active screen (in multi-monitor operation).
  - Double-click Button 1: Switch between full-screen mode (single camera) and multi-camera view.

#### User menu mode

- \* Primary function: Display and configuration of camera settings.
- \* Control options:
  - Button 1 + joystick (left/right): Cyclical selection of cameras.
  - Button 1 + joystick (forward/backward): Change the active screen.
  - Joystick (forward/backward): Select the parameter to be changed.
  - Joystick (left/right): Increase/decrease the parameter value.
  - Automatic value acceptance: Changes are saved when:
    - a. A new parameter is selected,
    - b. The camera is changed,
    - c. The user menu is exited.



### Mode changel

Standard mode: When the system starts up, MRX.marine is in camera display mode.

Mode switch: Pressing button 2 switches between camera display and user menu.

### Technical information

PTZ support: Depends on the camera model (visualised by icons).

Zoom function: Only active on cameras with zoom support.

Rotation (Z-axis): No function in the user menu.

Note: Operation is carried out either via the MRX.ptzController or the touch monitors.

### Overview

Button	Move		Context	
			Camera Display	User Menue
			Zoom / Zoom Out	--- / ---
			Move CAM Left / Right	selected value decrease / increase
			Move CAM Down / Up	Select previous / next value
Button1 +			--- / ---	--- / ---
Button1 +			Select previous / next CAM	Select previous / next CAM
Button1 +			Select previous / next monitor	Select previous / next monitor
Button2	---	---	Open user menue	Close user menue

